



THE WIRELESS POKER CONTROLLER™

The Wireless Poker Controller™ is a new and revolutionary device designed to assist game play within an Online Poker Room.

The Wireless Poker Controller™ helps poker players to make more accurate moves in a fast & comfortable manner.

Each Poker Controller™ comes fully featured with:

- A pinpoint Raise-O-Meter™ (bet wheel)
- Dedicated Check, Call & Fold buttons
- Predefined Bet Jump levels
- Lightning-fast Table Switches
- A 'laptop style' Mouse Touch-Pad
- Various Additional Table and Play options

The Wireless Poker Controller™ can assist players of any level, even the most seasoned player, to increase their bet speed & accuracy, avoid errors and play more accurately and efficiently.

The Poker Controller™ even features an emergency 'TILT' switch which can be programmed by the player to automatically lock them out for a cool-off period after a bad beat or losing session.

All in all, more control, much more comfort and more time to enjoy the game you love to play!

THE DESIGN

User-friendly, Ergonomic and Practical Design

The Poker Controller™ has been designed to offer maximum functionality in a minimalistic form, creating a stylish gaming device which will complement any surface or style of play.

Months of research & development and numerous design revisions have resulted in a Poker Controller™ specifically designed to offer maximum gaming comfort for extended periods of time.

From the finger placements on the rear of the device to the angle, size and height of the buttons, much research & development has gone into making the most comfortable and functional handheld device for use over long periods.

Should you wish to place the Poker Controller™ on a table top or your lap, discreet non-slip rubberised feet will ensure constant grip for all-round comfort.

Laid back, comfortable wireless game play promotes well thought out moves and a confident game. No more back strain from bending over the desk and no more strain on the wrist from using the mouse. Now you can concentrate more on the poker game itself!



BUTTON FUNCTIONALITY



THE FEATURES & **BUTTONS**



Pinpoint Raise-O-Meter™

Bets will increase by small, specific increments at the turn of a dial allowing for accurate and fast betting every time. The Raise-O-Meter™ can also be used in tandem with the preset bet levels to enable a fast jump to the desired amount followed by precision fine tuning with the Raise-O-Meter™ before confirming the bet.



Bet, Check or Fold

3 easy-to-reach buttons each sporting their own unique shape and angle, dedicated to the core functions of any poker game. These three buttons are always focussed solely on the 3 core moves of the game and are easily accessible and identifiable on the Poker Controller™.



Pre-defined Bet Levels

5 quick-fire raise amounts - X2, X3, X5, Pot & All-in - Use these one click buttons to bet pot, go all-in or simply jump to your desired bet level. Use any combination of buttons on the Poker Controller™ to reach the perfect bet amount.



Lightning Fast Multi-Table Switches

Two ergonomically placed buttons on either side of the Poker Controller™ enable the player to change tables quickly and safely. An on-screen indicator alerts you to the fact that you've changed tables and window-specific focussing alleviates clicking on the wrong table.



Anti TILT lock-out feature

When going on tilt, you can prevent emotional mistakes by pressing the TILT button, a new and totally unique feature of the Wireless Poker Controller™. This anti-tilt feature will freeze you out of the game for a period of time preset by the player with a countdown timer displaying the time left until you can resume.



Power ON/OFF, Menus & Table Play Shortcuts

The largest button on the wireless Poker Controller™ turns the device on/off and also features an auto-shutoff after 10 minutes of being idle. The Power button also acts as a menu shortcut screen providing access to the Poker Controller™ settings page. Various play settings shortcuts are also available directly above the power button, such as Auto Post Blind, Wait for Big Blind, Sit Out/In, Lobby and an Enter button for on-screen prompts.



PLAYER BENEFITS

No Mis-Clicks	Clearly identifiable and dedicated buttons will preclude mis-clicks.
No Missed Turns	Fast and accessible buttons ensure prompt betting at all times.
Accurate & Faster Betting	A pinpoint Raise-O-Meter™ guarantees fast and precise bet amounts.
Increased Game Speed	More players using a Poker Controller™ will mean faster game play.
Continuous Game Focus	The Poker Controller™ remains focused on the game for instant play.
Comfort & Reassurance	Comfortable and simple controls promote confident game play.
Health Benefits	Reduces back, wrist and eyesight problems from long sessions.
Reduced Tilt-Based Play	Fewer mistakes, more comfort and a 'TILT' button for a failsafe exit.
Heightened Engagement	Holding the tool that will shape your success, with memorable buttons to alleviate the need to look down or focus the mouse.
Potential Financial Gain	Easy controls means less stress and a higher chance of success.



TECHNICAL SPECIFICATIONS

Instant Wireless Connectivity

Using the latest 2.4 GHz Wireless technology, the Poker Controller™ can be operated with a Wireless range of up to 10 meters, offering you the freedom to relax and play where you feel most comfortable.

Up to 40 Hours Battery Life

The Poker Controller's™ carefully selected internal components allow the device to draw minimum power from the batteries, facilitating up to 40 hours of game-play on non-rechargeable batteries. The Wireless Poker Controller™ is programmed to also alert the player when the battery power is low and the device needs recharging.

Auto Battery Saving

To reduce battery wastage, the Poker Controller™ has been designed with power saving in mind and features an Auto Switch-off function that turns off the Poker Controller™ after 10 minutes of inactivity.

Emergency USB Cable Charging

In order to avoid any loss of play, the Poker Controller™ has been created to enable battery charging during game-play, just connect the Poker Controller™ to the supplied USB Cable and plug the other end into your computer; you can now play directly via the USB cable until you replace or fully charge the batteries.

MINIMUM SYSTEM REQUIREMENTS

OS	WINDOWS XP/ WINDOWS VISTA
Processor	XP: 300MHz OR HIGHER; VISTA: 600 MHz OR HIGHER
Memory	XP: 512MB RAM; VISTA: 1GB RAM
Hard Drive	50MB AVAILABLE DISK SPACE
CD-Drive	4 x SPEED
Input	1x USB PORT
Internet	56 KPS OR FASTER
Software	.NET FRAMEWORK 1.1